AVerMedia®

AVer MediaCenter

User Manual

DISCLAIMER

All the screen shots in this documentation are only example images. The images may vary depending on the product and software version. Information presented in this documentation has been carefully checked for reliability; however, no responsibility is assumed for inaccuracies. The information contained in this documentation is subject to change without notice.

COPYRIGHT

© 2009 by AVerMedia TECHNOLOGIES, Inc. All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form by any means without the written permission of AVerMedia TECHNOLOGIES, Inc.

International Headquarter

Address	No. 135, Jian-Yi Road Chung-Ho City, Taipei Hsien Taiwan
Website	www.avermedia.com
Telephone	886-2-2226-3630

MCS-1.7.3
200906

Table of Contents

Chapter 1 Introduction 1

1.1 Device Introduction 2

1.2 System Requirements 3

1.3 Activating AVer MediaCenter 3

1.4 Overview of AVer MediaCenter 4

The Main Screen 4

The Main Control Buttons 5

Navigation Tree 6

1.5 Remote Control 7

Overview of the Remote Control (model 1) 7

Overview of the Remote Control (continued) 8

Overview of the Remote Control (model 2) 9

Overview of the Remote Control (continued) 10

Overview of the Remote Control (model 3) 11

1.6 Running AVer MediaCenter for the First Time 12

Chapter 2 Getting Started 14

2.1 TV 15

Scanning TV Channels 15

Watching Live TV 16

Selecting a TV Channel 16

Adjusting Volume 17

Specifying a Channel Name or Description 17

Fine Tuning Color and Quality of the Display 18

Deleting a Channel 19

Editing the Channel Group Table 20

Managing the Channel Groups 21

Using OverScan Function 23

Changing the TV Channel Order 23

Capturing Images 24

Recording a TV Program Directly 24

Playing a Recorded TV Program 24

Viewing Teletext Information (Available for PAL / SECAM or DVB-T System) 25

Viewing EPG Information (Only Available for Digital TV) 25

2.2 Radio 27

Scanning FM Radio Frequencies (Only available for FM Radio) 27

Listening to the Radio 28

Manually Scanning Specific FM Channels (Only available for FM Radio) 28

Selecting a Radio Channel 29

Adjusting Volume 29

Deleting a Channel 29
Changing the Radio Channel Order 30
Recording a Radio Program Directly 30
Playing a Recorded Radio Program 31
Setting the Audio Mode (Only Available for FM Radio) 31
Viewing RDS Information (Optional) 32
2.3 Video 33
Playing Video Files 33
2.4 Music 34
Adding Music to your Playlist 34
Playing Music 35
2.5 Pictures 36
Viewing the Captured Images 36
Playing Slide Show 36
Chapter 3 Advanced Operations 37
3.1 TV 38
Using Schedule Recording 38
Using TimeShift 40
Switching Between TV and External Video 40
Multi-Source Display (Only Available for Multi-Source Tuner Series Users) 41
Multi-Channel Display (Only Available for Multi-Card/Dual Tuner Series Users) 43
Multi-Program Display (Only Available for Digital TV) 44
3.2 Radio 47
Using Schedule Recording 47
Using TimeShift 49
3.3 Video 50
Picture-in-Picture(PIP) / Picture-by-Picture(PBP) Display 50
Chapter 4 More Settings 51
4.1 General Settings 52
Configure Storage 52
Configure Snapshot 53
Video Device (Only Available for Multi-Card / Dual Tuner Series Users) 54
More Options 55
4.2 TV Settings 56
Configure Analog TV / Configure Digital TV ➔ Configure TV Signal 56
Configure Digital TV ➔ Configure TV Signal (Only for DVB-S users) 56
Configure Analog TV / Configure Digital TV ➔ Manage Programs 58
Configure Analog TV / Configure Digital TV / HD Input Source➔ Configure Recording 59
Configure Analog TV ➔ Configure Timeshift 59
Configure HD Input Source ➔ Configure Timeshift 60
Configure Analog TV / Configure Digital TV ➔ Configure Color Adjustment 60
More TV Options 61

4.3 Radio Settings 62
Manage FM Radio Programs / Manage Digital Radio Programs 62
Configure FM Radio Recording / Configure Digital Radio Recordings 63
4.4 Video Settings 64
4.5 Picture Settings 65
4.6 About 66

Appendix 67
Hot Keys 68
Glossary 69
Satellite Internet Access 71
Universal DVB Plug-in 74
Video Gaming Plug-in (for Microsoft Vista MCE only) 75
Video Quality Enhancement Plug-in (for Microsoft Vista MCE only) 76
Common Interface for Conditional Access 78

Chapter 1
Introduction

Thanks for purchasing AVer MediaCenter. This powerful application allows you to watch TV, listen to the radio, create slide shows, record favorite programs and enjoy other features on your PC. With our easy-to-use remote control, you can enhance your PC experience. Turn your computer system into a real multimedia entertainment center.

This Chapter will guide you through the essential information of AVer MediaCenter. Please do read this chapter before using this application.

Please be noted the functions and images may vary depending on the product you purchase and the area you live.

Device Introduction 2
System Requirement 3
Activating AVer MediaCenter 3
Overview of AVer MediaCenter 4
Remote Control 7
Running AVer MediaCenter for the First Time 12

CHAPTER 1

1.1 Device Introduction

Thanks for purchasing AVerMedia's product. **Please be noted that the functions or the remote control mentioned in this manual may vary depending on the product you purchase and the area you live.**

Product Name	AVerTV CaptureHD
Model No.	H727
TV System	☑ Digital TV (☑ DVB-T □ ATSC □ DVB-S) ☑ Analog TV (☑ NTSC ☑ PAL ☑ SECAM)
Audio Mode	☑ Stereo ☑ Mono ☑ SAP
FM Radio	☑ Support □ Not Support
Remote Control	☑ Support (□ Model 1 ☑ Model 2 □ Model 3) □ Not Support
External Signal Source	☑ S-Video ☑ Composite ☑ Component ☑ HDMI
Others	☑ Teletext □ MHEG-5 ☑ EPG ☑ iEPG ☑ Closed Caption ☑ Digital Subtitle □ CI/CA (optional) ☑ Multi-Source Display
Note	iEPG is only supported in USA
Appendix	□ Satellite Internet Access (for Window XP only) □ Universal DVB Plug-in (for Microsoft XP / Vista MCE, 32 bit only) □ Video Gaming Plug-in (for Microsoft Vista MCE only) □ Video Quality Enhancement Plug-in (for Microsoft Vista MCE only) □ Common Interface for Conditional Access (optional)

☑ Note: DVB is a registered trademark of the DVB Project.

1.2 System Requirements

System requirements are described in detail below. Before using *AVer MediaCenter*, verify that your PC meets the requirements below.

- ✓ Pentium 4 2.4GHz (Hyper-Threading) or Pentium Mobile 1.8GHz or above
- ✓ VGA card with 128M memory supports DirectX 9.0 or above
  For HDTV, VGA card should support DXVA
- ✓ 512MB RAM or above
- ✓ Sound Card
- ✓ 200MB HD size
- ✓ Windows XP SP2 / Windows XP MCE / Windows Vista™ / Windows Vista™ MCE

For TimeShift and Record in MPEG-2：

- ✓ Intel Pentium® 4 3.0 GHz (Hyper-Threading)

For HDTV (H.264) preview / HD Input Source (HDMI/YPbPr Component) Full Function

- ✓ Intel® Core™2 Duo E6600 2.4 GHz
- ✓ 1G RAM or above

1.3 Activating AVer MediaCenter

To run the application, click **Start**, point to **Programs**, choose **AVerMedia**, select AVer MediaCenter and then click **AVer MediaCenter**. Another way is to double-click the **AVer MediaCenter** program icon " "on the desktop. Or, you can double-click the **AVer Quick "** **"** launcher located in the lower right corner of the screen.

☑ **Note**: **AVerQuick** allows to set the desired default application, which means you can choose either AVerTV 6 or AVer MediaCenter as the default application when double clicking **AVerQuick** icon . To do this, right click **AVerQuick**, choose "**Setting**", and select the preferred application in the "**Application**" tab.

1.4 Overview of AVer MediaCenter

After running the software, the main screen of AVer MediaCenter appears, which includes “TV”, “Radio”, “Video”, “Music”, “Pictures” and “Settings”. This section briefly introduces main menu, sub menus and setting items. For more details, please refer to Chapter 2.

➢ The Main Screen

	Description
❶	Title bar
❷	Main menu
❸	Main window
❹	TV monitor and control panel
❺	Display the system time

☑ **Note**: You will not see the TV monitor and control panel until scanning TV channels.

The Main Control Buttons



	Description
	Go back the main menu
	Go back one level
	Open user manual
	Minimize the application
	Restore the previous size
	Exit the application

	Description
/	Switch from real-time TV or Radio to TimeShift mode. / Freeze the playback temporarily.
	Stop the playback, recording, TimeShift, etc.
	Play the selected file
	Record the current program.
	Play the previous/next file in the playlist.
	Move backward or skip forward in intervals.
	Capture a single image or a sequence of images.
	Enable the PIP or multiple channel display function.
	Switch to display all the programs that are under the same frequency simultaneously. (This function is only available for digital TV.)
	Switch to different aspect ratios.
CH	Go to the next upper or lower active channel.
	Turn on / off the sound.
	Increase or decrease the sound.
	Choose between available audio modes

Navigation Tree



☑ **Note**: The items may vary depending on the product you use and the area you live.

1.5 Remote Control

The remote control supports all the features of AVer MediaCenter. To use, just point the remote control at the receiver, and press button.

➢ Overview of the Remote Control (model 1)



	Button	Description
(1)		Turn on/off the application.
(2)	Sleep	Set the time to put your computer into Standby/Hibernate mode, exit the application or turn off the computer.
(3)	Text	View Teletext / Close Caption information.
(4)	Pos	**PIP Mode**: Turn on/off the PIP-positioning function. When enabled, you can move the selected screen using the arrow buttons.
(5)		Use numeric buttons to select a channel. Use Clear to delete the unwanted digit or letters.
(6)	Back	Go back to the previous page.
(7)	Info	Display the current program's information. (This function is not available for this device.)
(8)	CH	Channel up and channel down.
(9)	EPG	View EPG information.(This function is only available for digital TV and radio)
(10)	Snapshot	Capture an image or a continuous sequence of images.
(11)	TV	**Main Screen**: A shortcut to the main menu--"TV". **Teletext Mode**: Jump to the teletext page of the corresponding color according to this button.
(12)	Video	**Main Screen**: A shortcut to the main menu-- "Video". **Teletext Mode**: Jump to the teletext page of the corresponding color according to this button.
(13)	TimeShift	Switch from real-time TV or Radio to TimeShift mode.
(14)		Play the selected file or temporarily freeze the playback.
(15)		Go to the previous item in the playlist.
(16)		Move backwards in intervals.
(17)	Source	Change between available signal sources.

➢ Overview of the Remote Control (continued)



	Button	Description
(18)	Aspect	Switch to different aspect ratios (4:3, 16:9, Full Screen, Keep Aspect Ratio).
(19)	Live	Switch to live TV source in full screen.
(20)	Size	**PIP Mode:** Turn on/off the PIP-sizing function. When enabled, you can enlarge or shrink the selected screen using the arrow buttons.
(21)	PIP	Activate the Picture in Picture(PIP) / Multi-Channel Display function.
(22)	Home	Go to the main menu.
(23)	OK	**Main Screen**: Use the arrow button to navigate all on-screen items. Use OK to confirm the selection. **PIP Mode:** Move or change size of the selected screen by the arrow buttons.
(24)	Select	- Confirm the selection. - Choose item from the drop-down list.
(25)	Mute	Turn off/on the sound.
(26)	VOL	Volume up / Volume down.
(27)	Audio	Change between available audio modes.
(28)	Picture	**Main Screen**: A shortcut to your main menu--"Pictures". **Teletext Mode**: Jump to the teletext page of the corresponding color according to this button.
(29)	Music	**Main Screen**: A shortcut to your main menu--"Music". **Teletext Mode**: Jump to the teletext page of the corresponding color according to this button.
(30)	■	Stop the playback, recording, TimeShift, etc.
(31)	●	Record the current program.
(32)	▶I	Go to the next item in the playlist.
(33)	▶▶	Skip forward in intervals.
(34)	CH RTN	Return to previously accessed channel.

➢ Overview of the Remote Control (model 2)



	Button	Description
(1)	Power	Turn on/off the application.
(2)	Mute	Turn off/on the sound.
(3)		Use numeric buttons to select a channel.
(4)		Display TV in full screen.
(5)	Audio	Change between available audio modes.
(6)		**Main Screen**: Use the arrow button to navigate all on-screen items. Use OK to confirm the selection. **PIP Mode:** Change size or position of the selected screen by the arrow buttons.
(7)		Volume up / Volume down.
(8)	Video	**Main Screen**: A shortcut to the main menu--"Video". **Teletext Mode**: Jump to the teletext page of the corresponding color according to this button.
(9)	TV	**Main Screen**: A shortcut to the main menu--"TV". **Teletext Mode**: Jump to the teletext page of the corresponding color according to this button.
(10)	Text	View Teletext / Close Caption information.
(11)	EPG	View EPG information. (This function is only available for digital TV)
(12)		Record the current program.
(13)		Play the selected file or temporarily freeze the playback.
(14)	Wake up	- Go to the previous item in the playlist. - Set the time to bring your computer out of Stand By or Hibernate mode. (This function is only available for AVerTV 6)
(15)		Move backwards in intervals.

➢ Overview of the Remote Control (continued)



	Button	Description
(16)		Skip forward in intervals.
(17)	Sleep	- Go to the next item in the playlist. - Set the time to put your computer into Stand By / Hibernate mode, exit the application or turn off the computer. (This function is only available for AVerTV 6)
(18)		Stop the playback, recording, TimeShift, etc.
(19)	TimeShift	- Switch from real-time TV or Radio to TimeShift mode. - Temporarily freeze the playback. (This function is only available for AVerTV 6)
(20)	PIP	Activate the Picture in Picture (PIP) / Multi-Channel Display function.
(21)	Snapshot	Capture an image or a continuous sequence of images.
(22)	Picture	**Main Screen**: A shortcut to the main menu--"Pictures". **Teletext Mode**: Jump to the teletext page of the corresponding color according to this button.
(23)	Music	**Main Screen**: A shortcut to the main menu--"Music". **Teletext Mode**: Jump to the teletext page of the corresponding color according to this button.
(24)	CH	Channel up and channel down.
(25)	Back	Go back to the previous page.
(26)	Home Exit	- Go to the main menu. - Exit from CI/CA Information dialog. (This function is only available for CI/CA)
(27)	Ch Rtn	Return to previously accessed channel.
(28)	Source	Change between available signal sources.

➢ Overview of the Remote Control (model 3)



Button	Description
1. SOURCE	Switch between available signal sources.
2. FULL SCREEN	Display TV in full screen.
3. ● (Record)	Switch to PVR mode and record the current program or video into your hard drive.
4. ◂◂ (Rewind)	Rewind the playback.
5. ■ (Stop)	- End the Playback or recording. - End the TimeShift mode and return to real-time TV or Radio mode.
6. DISPLAY	Display information.
7. VOL＋/－	Volume up/down.
8. Numeric Buttons	- Select a TV channel. - Under the 16-Channel preview mode, use 2 4 6 8 to highlight the intended channel. (This function is only available for AVerTV 6)
9. CH RTN	Go to the previously selected channel.
10. MUTE	Turn on/off the sound.
11. CH ▲/▼	Go up or down to the next active channel.
12. EPG	Launch the Electronic Program Guide. (DVB-T only)
13. ► (Play) / PAUSE	Play the last recorded or played file. / Freeze the playback.
14. ▸▸ (Forward)	Advance the playback.
15. AUDIO	Switch between available audio modes.
16. POWER	Turn on/off the application

1.6 Running AVer MediaCenter for the First Time

When you run the AVer MediaCenter for the first time, a set up wizard will automatically appear and take you through all the necessary settings step by step.

1. When a dialog box appears, click **Yes.**
2. Choose the primary device or tuner for watching TV or listening to the radio and then select **Next** (as shown on the right). Then choose **Next** again to continue.



3. Choose the country where you located and select the correct S-Video and Composite Video Standard. Then select **Next**.
4. Then the wizard will show the setting process and lead you to set up all available signal sources (As shown on the right). Select **Next** to continue the process or select **Skip** to ignore the setting.
5. Determine the TV source and select **Next**.

6. Select AutoScan to start scanning (As shown on the right). After scanning, select **Next** to continuously set up other signal sources if any.



7. After finishing all settings, select **Finish**.

8. Select **Next** to continuously set up other device if any.

9. If you want to re-configure all the settings again, go the main page and select "**Select**"➔ "**General**" ➔ "**Run Wizard Again**."



Chapter 2
Getting Started

This Chapter will start with the basic usage of AVer MediaCenter, including scanning programs, playing music, recording a TV/ Radio program, and so on.
Before using the application, it is necessary to understand all the basic operations in this chapter.

TV **15**
Radio **27**
Video **33**
Music **34**
Pictures **36**

CHAPTER 2

2.1 TV

Under the **TV** main menu, you can enjoy watching TV, record your favorite program and so on.

➢ Scanning TV Channels

If you didn't run the setting up wizard, a dialog box will appear to prompt you to scan for channels when selecting the main menu "**TV**".

1. When the Program Information dialog box appears, select Yes.
2. Then the wizard leads you to the "Settings" page to automatically scan channels.

3. You can check the scanning progress from the progress bar. After scanning, the active TV channels will be listed inside the box.
4. Terminate the scanning, simply select Stop.
5. If there are channels missing, select All Frequency Scan. This may take you a while, please be patient.

☑ **Note**:

1. If you didn't follow the wizard to automatically scan channels, you can select "**Settings**" ➔ "**TV**" ➔ "**Configure Analog TV**" or "**Configure Digital TV**" ➔ "**Manage Programs**" and choose **Auto Scan** to scan for channels.
2. After Media Center Edition scan, you may not be able to lock channels with AVerTV 6. Please restart the computer to make it function normally.

➢ Watching Live TV

You can enjoy analog TV, digital TV or both of them depending on what your product is.

1. After scanning, go to the **TV** page and you can see a preview TV window in the right-hand section of the screen.
2. To switch the preview mode to the full-screen mode, select **Live**.



3. If you want to go back the preview mode, press Back on the remote control or select in the top-left corner of the screen.



➢ Selecting a TV Channel

There are four ways of switching between TV channels:

1. Use the numeric keys on the remote control to get your desired channel.
2. Use the **Channel Up/Down** buttons (on the remote control or CH on the control panel) repeatedly until reaching your desired channel.
3. Enter the number on your numeric keypad to get your desired channel.
4. Select the **Program List** and select the channel you want.

➢ Adjusting Volume

To increase or decrease volume when watching TV, press on the remote control or click on the control panel.

To disable the sound of the program, press on the remote control or click on the control panel. Press the same button again to turn on the sound.

➢ Specifying a Channel Name or Description

To assign a channel name or specify description:

1. Select "**Settings**" ➔ "**TV**" ➔ "**Configure Analog TV**" or "**Configure Digital TV**" ➔ "**Manage Programs**"
2. Select the desired channel you want to assign a name or description.



3. Enter the name or description under the **Channel Name**.
4. Choose the preferred audio mode from the drop down list.
5. Select **Save** to save the settings or select **Cancel** to abort without saving. If you want to revert to factory settings, select **Default**.



➢ Fine Tuning Color and Quality of the Display

If the color and quality of a particular channel needs to be adjusted, please do the following.

1. Select "Settings" ➔ "**TV**" ➔ "**Configure Analog TV**" or "**Configure Digital TV**" ➔ "**Manage Programs**"
2. Select the desired channel.
3. Select in the bottom-right of the screen to go to the second page.



4. Then use to adjust the **Brightness**, **Contrast**, **Hue**, **Saturation** and **Sharpness** until the image color is accurate.
5. You will need to perform fine-tune only if the reception of the selected channels is not clear. Use to get a clear TV picture.



6. If the device you use can watch analog TV, here you can also select the **Noise Reduction** check box to obtain the better quality.
7. Select **Save** to save the settings or select **Cancel** to abort without saving. If you want to revert to factory settings, select **Default**.



☑ **Note**: By default, the system is set to disable the color adjustment items. To adjust image color of one specific channel, you need to go to "**Settings**" ➔ "**TV**" ➔ "**Configure Analog TV** or "**Configure Digital TV**"➔ **Configure Color Adjustment**" and clear the **Apply All** check box. After clearing the **Apply All** check box and select **Save**, you can now adjust the setting of a specific channel.

➢ Deleting a Channel

If you want to exclude undesirable channels from your channel list, do the following:

1. Select "**Settings**" ➔ "**TV**" ➔ "**Configure Analog TV**" or **"Configure Digital TV"**➔ "**Manage Programs**".
2. Select the unwanted channel.
3. Choose . This channel will be removed and that means you won't be able to access these programs anymore. If you want to watch that channel again in some day, you need to rescan all channels.



4. If you just want to skip a particular channel, simply clear the check box.

➢ Editing the Channel Group Table

To add or remove channels from the channel group, do the following:

1. Select "**Settings**" ➔ "**TV**" ➔ "**Configure Analog TV**" or **"Configure Digital TV"**➔ "**Manage Programs**" ➔ "**Group Setting**".



2. The default and the first channel group*[Note] are listed in the **Group Setting** table.
3. You can see all groups in this table. (To see more groups in the table, use arrow buttons in the right bottom corner of the screen).
4. If you choose "Configure Digital TV" in step, there will be an additional option "By Content Provider" on this page. This option allows you to classify channels that are under the same frequency into one group.
5. Click the cell to add the desired channel in the channel group. The mark V appearing indicates that channel has been added in the group.
6. Click the cell again to remove the channel from the channel group.
7. The new setting will be saved automatically.



☑ **Note**: If you want to search a channel by channel name, select **Search**.

➢ Managing the Channel Groups

Channel groups are used to organize and group channels that suit your needs. To manage your channel groups, do the following:

1. Select "**Settings**" ➔ "**TV**" ➔ "**Configure Analog TV**" or **"Configure Digital TV"**➔ "**Manage Programs**"➔ "**Group Setting**" ➔ "**Modify**".



2. If you want to create a new channel group, select **Add**. You can also select the existed group to enter the next page to modify the group name.

3. Type in a group name and click **Save**.

4. You can use to remove a channel group or use to move the channel group to the desired location.



5. The first channel group will be shown in the **Group Setting** table.

➢ Using OverScan Function

On some broadcast channels, you might see distorted lines or black spaces on the top, sides, or bottom of the screen. These video artifacts derive from the source signal, and can be masked using the **OverScan** feature.

1. Select "**Settings**" ➔ "**TV**" ➔ "**Configure Analog TV**" or "**Configure Digital TV**" ➔ "**Manage Programs**"
2. Select the channel you want to hide the edges of the picture.
3. Specify an appropriate number (0~20) to get the better quality.
4. Select **Save** to save the settings or select **Cancel** to abort without saving. If you want to revert to factory settings, select **Default**.



☑ **Note**: By default, the system is set to disable the Overscan item. To apply the overscan setting to one specific channel, you need to go to "**Settings**" ➔ "**TV**" ➔ "**Configure Analog TV**" or "**Configure Digital TV**"➔ "**Configure TV Signal**" and clear the **Apply All** check box. After clearing the **Apply All** check box and select **Save**, you can now adjust the setting of a septic channel.

➢ Changing the TV Channel Order

You may change the sequence of channels as you prefer.

1. Select "**Settings**" ➔ "**TV**" ➔ "**Configure Analog TV**" or "**Configure Digital TV**"➔ "**Manage Programs**".
2. Select the channel you want to move.
3. Use to move upward or downward until the selected channel moves to the desired location.



➢ Capturing Images

While you watch TV or recorded video from your PC monitor, you can use the application to capture images for your document, presentation or web page.

1. Select "**TV**".
2. Press Snapshot on the remote control or select on the control panel to capture a still image. To capture another image, press that button again.
3. To view the captured images, go back the Main Menu and select main menu "**Pictures**". All the pictures are listed in the right-hand section of the screen.

☑ **Note**: For details, refer to the section titled "**Pictures**" in *Chapter 2*.

➢ Recording a TV Program Directly

To record a program now:

When watching TV, select to record a program immediately. To stop recording, select .

➢ Playing a Recorded TV Program

1. Select "**TV**" ➔ "**Recorded Files**".
2. All the recorded files are listed here.
3. You can view those file by date, title or status.
4. Choose the desired file.
5. If you want to delete all recorded files, click the **Remove All** button→Yes.

6. Select **Play**.
7. To switch to the full-screen, double-click the small TV monitor.
8. To temporarily pause the playback, select . To stop the playback, select .

☑ **Note**: For the related information, refer to "**Video**"➔ "**Playing Video Files**" in *Chapter 2*.

➢ Viewing Teletext Information (Available for PAL / SECAM or DVB-T System)

Teletext makes TV viewing a unique experience. It allows you to view teletext broadcasts from your television programs to get the most updated information on TV Schedules, News, Stock Market Prices, Concert & Theatre information and so on. Teletext information may not be available if there is no such service provided in your region or country.

1. Select "**TV**" ➔ "**Teletext**".
2. Teletext information overlays on the TV monitor.
3. Press

on the remote control to jump to the Teletext page of the corresponding color.
4. Or press the numeric buttons on the remote control to go to your desired page.

➢ Viewing EPG Information (Only Available for Digital TV)

Electronic Program Guide (EPG) is a service that allows you to check the next succeeding program schedule and even the program schedules of the whole week. If the EPG service is provided in your region/country, do the following to view the EPG information. (For Analog TV: if the country you choose is the United States in Chapter 1.6, the iEPG function will be enabled.)

1. Select "**TV**" ➔ "**EPG**".
2. You can use to choose the desired day.
3. Then Use in the lower right of the screen to find the channel you want. To select other period of time, use .
4. Select **Update** to download the latest program schedule.



5. Select the desired program.
6. To record the program for future viewing, use **Scheduling**.
7. To tune into the program for some time in the future, use **Activate Live TV**.

8. Use to go back the **EPG** page.
9. Select **Search Programs** to have the advance searching function.
10. On the next page (as shown on the right), you can search by key words, time, program type and the parental rating.
11. After setting all conditions, select **Search**.

☑ **Note**:

1. For more details on establishing a schedule, refer to "**Using Schedule Recording"** in *Chapter 3*.
2. "**Type**" and "**Parental Rating**" are only effective when your EPG system transmits information about the program type and parental rating.

2.2 Radio

If the product you purchase with radio function, then you can read this chapter to learn more knowledge about this.

➢ Scanning FM Radio Frequencies (Only available for FM Radio)

If this is your first time running the application, a dialog box will appear to prompt you to scan for channels when selecting the main menu "Radio".

1. When the **Program Information** dialog box appears, select **Yes**.
2. Then the wizard leads you to the "**Settings**" menu to auto scan channels.

3. You can check the scanning progress from the progress bar. After scanning, the active FM Radio channels will be listed inside the box.
4. If there are channels missing, select **All Frequency Scan**. This may take you a while, please be patient.

☑ **Note**: If you didn't follow the wizard to automatically scan channels, you can select "**Settings**" ➔ "**Radio**" ➔ "**Configure FM Radio**" or "**Configure Digital Radio**" ➔ "**Manage Programs"** and choose **Auto Scan** to scan for channels.

➢ Listening to the Radio

You can enjoy listening to the FM Radio, digital radio or both of them depending on what product you purchase.

1. After scanning, go to the **Radio** page and you can see all available channels listed in the right-hand section of the screen.
2. Select the channel you want.
3. Select **Live Radio** to listen to the live program.



➢ Manually Scanning Specific FM Channels (Only available for FM Radio)

Instead of scanning all channels, you can manually scan one or a few channels only.

1. Select "**Radio**" ➔ "**Add Program**".
2. Enter the channel frequency that you want to start scanning in the text box.
3. In the **Seek** section, use to scan upward or to scan downward from the selected channel frequency. The scanning will stop when the application finds the closest ACTIVE FM frequency.
4. Or in the **Tune** section, select or to increase or decrease the frequency to search your preferred channel.
5. Select **Save** if you'd like to keep the newly scanned frequency. Or select **Cancel** to abort without saving.

➢ Selecting a Radio Channel

There are three ways of switching between radio channels:

1. Use the numeric keys on the remote control to get your desired channel.
2. Press the **Channel Up/Down** buttons (on the remote control or CH on the Control Panel) repeatedly until reaching your desired channel.
3. Enter the number on your numeric keypad to get your desired channel.

➢ Adjusting Volume

To increase or decrease volume when listening to the FM radio, press the **Volume +/-** on the remote control or press the button on the control panel.

To disable the sound of the program, press Mute on the remote control or select on the control panel.

Press the same button again to turn on the sound.

➢ Deleting a Channel

If you want to exclude undesirable channels from your channel list, do the following:

1. Select "**Radio**".
2. Select the unwanted channel.
3. Select **Delete** to remove the undesired channel. This channel will be removed and that means you won't be able to access these programs anymore. If you want to listen to that channel again in some day, you need to rescan all channels.

4. If you just want to skip a particular channel, do the following:
5. Select "**Settings**" ➔ "**Radio**" ➔ "**Configure FM Radio**" or "**Configure Digital Radio**"➔ "**Manage Programs**".
6. Choose the unwanted channel and clear the check box.

➢ Changing the Radio Channel Order

You may change the sequence of channels as you prefer.

1. Select "**Settings**" ➔ "**Radio**" ➔ "**Configure FM Radio**" or "**Configure Digital Radio**"➔ "**Manage Programs**".
2. Select the channel you want to move.
3. Use to move upward or downward until the selected channel moves to the desired location.

➢ Recording a Radio Program Directly

To record a program now:

When listening to the radio, select to record a program immediately. To stop recording, select .

➢ Playing a Recorded Radio Program

1. Select "**Radio**" ➔ "**Recorded Files**".
2. All the recorded files are listed here.
3. You can view those files by date, title or status.
4. Choose the desired file.

5. Select **Play**.
6. To temporarily pause the playback, select . To stop the playback, select .

➢ Setting the Audio Mode (Only Available for FM Radio)

The application will automatically set each FM radio channel to Mono or Stereo based on the audio mode of the FM radio signals received.

1. Select "**Settings**" ➔ "**Radio**" ➔ "**Configure FM Radio**" ➔ "**Manage Programs**".
2. Click on the channel. Select **Mono** or **Stereo** to get better audio quality.
3. Select **Save** to save the settings or select **Cancel** to abort without saving.

➢ Viewing RDS Information (Optional)

RDS (Radio Data System) is an international standard for transmitting the digital data along with FM Radio signal. An RDS-capable radio can display name of the station, program types, local traffic information or commercials, etc. To view RDS information, please do the followings:

1. After scanning, go to the **Radio** page and you can see all available channels listed in the right-hand section of the screen.



2. For those channels whose radio stations transmit RDS data, you will see a RDS button and the display name of the channel on the left-hand section of the screen.
3. Click RDS button, and you can see more information about the radio channels.

2.3 Video

With this function, you can view recorded programs or other video files.

➢ Playing Video Files

1. Select "**Video**".
2. You may see some recorded video files are listed on the right hand section of the screen. Or you can select **More Videos** to choose other folders.
3. Select the file you want.
4. Select on the control panel to stop the playback and return to live program.

   To pause the playback, press on the remote control or select on the control panel.



2.4 Music

You can create your music library and enjoy music with our AVer MediaCenter.

➢ Adding Music to your Playlist

Add your favorite music to AVer MediaCenter music playlist and then you can playback music from the playlist next time.

1. Select "**Music**" ➔ "**Add Music**" and then select the desired folder.
2. Choose the tracks you wish to play. Press Select on the remote control or **Space** button on your keyboard to confirm the selected file or folder.
3. Select **OK** to go back one level.

4. Then you can see the added files displayed in the right-hand section of the screen.
5. Use to remove one track or select **Remove All** to delete all tracks in the playlist.

➢ Playing Music

To playback music:

1. Select "**Music**".
2. Enable **Sequential** to play tracks in order or **Random** to shuffle the order.
3. To continue playing all the tracks, select **Loop** check box.
4. Use to determine the order of the tracks in your playlist.

5. Then select to start to listen to the music.
6. Use the following buttons to control your playback.

Advance the playback.

Rewind the playback.

Play the next track.

Play the previous track

Freeze the playback.

End the playback

2.5 Pictures

In this section, we introduce methods to view your pictures and play a slide show.

➢ Viewing the Captured Images

1. Select "**Pictures**".
2. The captured thumbnails are displayed in the right-hand section.
3. By clicking on the thumbnails, you can view images in a full-screen window.
4. Select **More Pictures** to find the folder that contains the desired pictures if your images are not saved in the default folder.

☑ **Note**: You can view thumbnails and enjoy live TV / radio or music at the same time.

➢ Playing Slide Show

1. Select "**Pictures**".
2. Select **Play Slide Show** to start a slide show.
3. To stop the slide show and go back to the previous page, press the button.



Chapter 3
Advanced Operations

Beyond basic usage, what else you can do with AVer MediaCenter? In this chapter, we take you to the next level and explain the advanced features of this application.

TV **38**
Radio **47**
Video **50**

CHAPTER 3

3.1 TV

➢ Using Schedule Recording

You may need to record a program for some time in the future, first go to the **TV** page, select **Schedule Recording** and then select **New Schedule**.

1. Choose the appropriate device. For instance, if you want to record digital TV program, you should choose the device that can receive digital signals.
2. Type the desired name for the recording in the **Schedule Name** text box.
3. From the **Task** drop-down list, select **Active TV Application** to tune into the desired channel. You can also select **Silent Recording** to perform background recording or select **Recording** to save a program for future viewing.

4. In the **After Recording Mode** option, it automatically switches to the selected power control mode when the schedule recording is completed. Choose an appropriate power control status listed below:
   - Launch Live TV: Switch to real-time TV mode.
   - Exit: Turn off the Application.
   - Log Off: Log off from windows.
   - Stand By: Turn off your monitor and hard disks.
   - Hibernate: Save everything and then turn off your computer.
   - Power Off: Shut down your computer.

5. Next, determine the signal source and channel.

6. In the **Task Period**, you can set the schedule once or on a daily/weekly basis.

7. Determine the file format and recording duration.

8. This application lets you to divide the recording files into parts for burning onto removable optical media, such as CD (650 MB) and DVD (4096 MB) discs. Select the **Split File Size** option and select the appropriate video file size from the drop-down list so that each video file will not exceed the limit. Or you can choose **Customize** to assign the file size you want.

9. Finally, choose the destination folder to save the recorded file.

10. Select **Save** to save the settings or select **Cancel** to abort without saving.



☑ **Note**:

1. Before establishing a schedule, please make sure that your system time is correct.

2. While you are away from your desk, you can put your computer into Stand By or Hibernate mode. When it comes to your setting time, your computer will come out of Stand By or Hibernate mode and start to execute the schedule recording. For details about configuring the power options, please refer to the documentation that came with your operating system.

➢ Using TimeShift

The TimeShift function performs background recording of a program, and lets you return to any part of the recorded program. At the same time, the live program continues to be recorded and played back so you won't miss any part of the show. You can also advance forward to skip commercials or rewind to replay scenes again.

1. Select "**TV**".
2. On this page, you can select **TimeShift**, press TimeShift on the remote control or select on the control panel. Then on the upper-right corner of the main screen displays the background recording time and the current-show time.
3. Select to move backward in fixed intervals until reaching the part where you left off.
4. To advance forward and skip some parts of the recording, select to move forward in fixed intervals.
5. To temporarily pause the playback, press on the remote control or choose on the control panel. To resume, select .
6. To return to the real-time program, select . This switches off the TimeShift function and returns you to the live program.

☑ **Note**: The application will create a temporarily recorded file when the TimeShift function is being performed for a program. This file will be removed when you select .

➢ Switching Between TV and External Video

If the device you use has external signals, you can watch video from an external source such as a VCR or camcorder:

1. Select "**TV**".
2. From the drop-down list, choose the type of video source.

➢ Multi-Source Display (Only Available for Multi-Source Tuner Series Users)

With the PIP/PBP feature, when you are using multi-source tuner series (such as AVerTV CaptureHD), you are able to watch many video sources (TV and external video) at the same time. To do so, please do the followings:

1. Select "**TV**".
2. From the drop-down list, choose the type of video source.



3. On this page, press PIP on the remote control or use on the control panel. You can see TV icons on the bottom-right corner of the screen. In this example, two TV icons appearing indicate two video sources.
4. Select and choose the type of video source from the drop-down list (Analog, DVB-T Composite, S-Video).
5. Select and choose the type of video source from the drop-down list (Component, HDMI).
6. You can choose either or to switch between different video sources.

7. Then, to display all available video sources simultaneously, select **Live**.

8. Select or repeatedly to switch between Full screen mode, PIP mode and PBP mode (as shown on the right).

(Full Screen Mode)

(PIP Mode)



(PBP Mode)

9. To change the video source, right click on the selected screen. When a pop-up menu appears, point to Source and select the type of video source you prefer.



10. Under PIP mode, to change size of the PIP screen, first press Size on the remote control. Then use ▲ ◀ to shrink the image or use ▶ ▼ to enlarge the image. To exit the PIP-sizing mode, press Size again.



☑ **Note**: Record function is not available in PIP/PBP display mode.

➢ Multi-Channel Display (Only Available for Multi-Card/Dual Tuner Series Users)

When you install two or more TV tuner cards or devices in the computer, this function allows you to watch many channels at the same time.

1. Select "**TV**".

2. On this page, press PIP on the remote control or use ⧉ on the control panel. You can see TV icons 1 on the bottom-right corner of the screen. In this example, two TV icons appearing indicates two devices are installed in this computer.

3. You can choose either 1 or 2 to switch between different TV signals.

4. To display all available TV signals simultaneously, select **Live**.

5. Select ⧉ or PIP repeatedly to switch between Full screen mode, PIP mode and PBP mode (as shown on the right).

6. To switch and listen to the sound of another TV signal, simply use the arrow button ←

(Full Screen Mode)

→ to select the PIP/PBP screen.

(PIP Mode)



(PBP Mode)

7. Under PIP mode, to change size of the PIP screen, first press Size on the remote control. Then use ▲ ◀ to shrink the image or use ▶ ▼ to enlarge the image. To exit the PIP-sizing mode, press Size again.



➢ Multi-Program Display (Only Available for Digital TV)

In the digital terrestrial field, a single channel (frequency) is able to carry more than one TV program at the same time. That's why usually there are only a few active channels found, but many programs are listed. This section tells you how to watch different programs that are under the same frequency (channel) simultaneously.

1. Select "**TV**".
2. On this page, use on the control panel. You can see TV icons on the bottom-right corner of the screen. In this case, three TV icons appearing means under the same frequency, there are three different programs.
3. You can choose TV icons to switch between different programs.



4. To display all available TV signals simultaneously, select **Live**.

5. Select repeatedly to switch between Full screen mode, PIP mode and PBP mode (as shown on the right).

6. To switch and listen to the sound of another TV signal, simply use the arrow button ← → to select the PIP/PBP screen.

(Full Screen Mode)

(PIP Mode)



(PBP Mode)

7. Under PIP mode, to change size of the PIP screen, first press Size on the remote control. Then use to shrink the image or use to enlarge the image. To exit the PIP-sizing mode, press Size again.



3.2 Radio

➢ Using Schedule Recording

You may need to record a program for some time in the future, first go to the **Radio** page, select **Schedule Recording** and then select **New Schedule**.

1. Choose the appropriate device. For instance, if you want to record digital radio program, you should choose the device that can receive digital signals.
2. Type the desired name in the **Schedule Name** text box.
3. From the **Task** drop-down list, select **Active TV Application** to tune into the desired channel. You can also select **Silent Recording** to perform background recording or select **Recording** to save a program for future listening.



4. In the **After Recording Mode** option, it automatically switches to the selected power control mode when the schedule recording is completed. Choose an appropriate power control status listed below:
   - Launch Live TV: Switch to real-time FM Radio mode.
   - Exit: Turn off the Application.
   - Log Off: Log off from windows.
   - Stand By: Turn off your monitor and hard disks.
   - Hibernate: Save everything and then turn off your computer.
   - Power Off: Shut down your computer.

5. Next, determine the signal source and channel.

6. In the **Task Period**, you can set the schedule once or on a daily/weekly basis.

7. Determine the file format and recording duration.

8. This application lets you to divide the recording files into parts for burning onto removable optical media, such as CD (650 MB) and DVD (4096 MB) discs. Select the **Split File Size** option and select the appropriate video file size from the drop-down list so that each video file will not exceed the limit. Or you can choose **Customize** to assign the file size you want.

9. Finally, choose the destination folder to save the recorded file.

10. Select **Save** to save the settings or select **Cancel** to abort without saving.

☑ **Note**:

1. Before establishing a schedule, please make sure that your system time is correct.

2. While you are away from your desk, you can put your computer into Stand By or Hibernate mode. When it comes to your setting time, your computer will come out of Stand By or Hibernate mode and start to execute the schedule recording. For details about configuring the power options, please refer to the documentation that came with your operating system.

➢ Using TimeShift

You can use the TimeShift function to perform background recording of a radio program and even replay.

To start the TimeShift Function:

1. Select "**Radio**".
2. Choose the desired channel to go to the next page.
3. On this page, you can select Radio TimeShift , press TimeShift on the remote control or select on the control panel. Then on the upper-right corner of the main screen displays the background recording time and the current-show time.
4. Select to move backward in fixed intervals until reaching the part where you left off.
5. To advance forward and skip some parts of the recording, select to move forward in fixed intervals.
6. To temporarily pause the playback, press on the remote control or choose . To resume, select .
7. To return to the real-time program, select . This switches off the TimeShift function and returns you to the live program.

☑ **Note**: The application will create a temporarily recorded file when the TimeShift function is being performed for a program. This file will be removed when you select .

3.3 Video

➢ Picture-in-Picture(PIP) / Picture-by-Picture(PBP) Display

With the PIP/PBP feature, you are able to playback recorded video files, and at the same time, watch live TV.

1. Select "**Video**".
2. On this page, choose the desired file. Or select **More Videos** to find other video files.
3. When playing the video file, press PIP on the remote control or use on the control panel to enable the PIP function.
4. Select or PIP repeatedly to switch between Full screen mode, PIP mode and PBP mode (as shown on the right).
5. By default, the playback recorded video is displayed on the main screen, and live TV is on the PIP/PBP screen.
6. To switch and listen to the sound of live TV, simply use the arrow button ← → to select the PIP/PBP screen.
7. Meanwhile, the control buttons on the screen may vary depending on the selected screen mode.
8. Under PIP mode, to change size of the PIP screen, first press Size on the remote control. Then use to shrink the image or use to enlarge the image. To exit the PIP-sizing mode, press Size again.

(Full Screen Mode)

(PIP Mode)



(PBP Mode)

Chapter 4
More Settings

Before scanning channels, recording programs, or capturing images, check the settings page to see if they meet your needs. With our explanation in this chapter, you can easily customize all the settings of AVer MediaCenter.

CHAPTER 4

General Settings **52**
TV Settings **56**
FM Radio Settings **62**
Video Settings **64**
Picture Settings **65**
About **66**

4.1 General Settings

Here you can select the destination folder for saving recorded files, determine recording time and file size, assign the number of image you want to capture, setting the Windows power options, etc.

➢ Configure Storage

1. Select "**Settings**" ➔ "**General**" ➔ "**Configure Storage**"
2. Use the default folder for saving the recorded files
3. Or select to look for your desired folder.

4. On the next page, you can use to go up one level to find other folders or select **Change Disk** to choose other hard drives.
5. Then Choose **OK** to confirm the selection.



6. Determine the length of recording time otherwise the system will record the largest clip that your hard drive can accommodate.
7. This application lets you to divide the recording files in parts for burning onto removable optical media, such as **CD Disc** (650 MB) and **DVD Disc** (4096 MB) discs. Select the **Split File Size** check box and choose the appropriate video file size from the drop-down list so that each video file will not exceed the limit. Or you can choose **Customize** to assign the file size you want.
8. Select **Save** to save the settings or select **Cancel** to abort without saving. If you want to revert to factory settings, select **Default**.

➢ Configure Snapshot

1. Select "**Settings**" ➔ "**General**" ➔ "**Configure Snapshot**".
2. In the **Number of Pictures** box, assign the number of images that you want to capture.
3. In the **Interval Time** box, specify the interval between captures. For instance, if you specify 10 seconds, an image will be captured every 10 seconds.
4. Choose the format you want for saving the captured images.
5. Use the default folder for saving images.
6. Or select to look for your desired folder.
7. On the next page, you can use to go up one level to find other folders or select **Change Disk** to choose other hard drives.
8. Choose **OK** to confirm your selection.
9. Select **Save** to save the settings or select **Cancel** to abort without saving. If you want to revert to factory settings, select **Default**.



➢ Video Device (Only Available for Multi-Card / Dual Tuner Series Users)

If you install two or more devices in your computer, for example AVerTV GO 007 Plus (M15C) and AVerTV Hybrid+FM Cardbus (E506R), you need to determine which device you want to use for watching TV, listening to the radio and other multimedia functions. For dual tuner series users, you also need to determine which tuner you want to use for watching TV.

1. Select "**Settings**" ➔ "**General**" ➔ "**Video Device**".
2. Choose the primary device from the drop-down list.
3. To use **Multi-Channel Display** function, you need to select the secondary devices. (For more details on this function, refer to "**Multi-Channel Display"** in chapter 3)
4. Select **Save** to save the settings or select **Cancel** to abort without saving.
5. To find out if your AVerMedia product supports multi-card feature, please refer to AVerMedia's website.



➢ More Options

This page allows you to set the power mode. Then you can put your computer in Stand By, Hibernate or other modes while you are away from the computer.

1. Select "**Settings**" ➔ "**General**" ➔ "**More Options**".
2. You can select the UI language you want from the **Language** drop-down list.
3. By default, the system is set to select **Enable Stand By / Hibernate Support**.

4. In the second page, determine the sleep function and choose the desired power-saving settings, including **Exit**, **Stand By**, **Hibernate** and **Power Off**.
5. Select the **Keep Sleep function after TV application closed** check box to enable the function.
6. Select the preferred video renderer from the drop-down list.
7. Select **Save** to save the settings or select **Cancel** to abort without saving. If you want to revert to factory settings, select **Default**.



☑ **Note**:

1. If your computer has problem with being out of Stand By or Hibernate mode, clear the **Enable Stand By / Hibernate Support** option.
2. Under Window Vista system, Enhanced Video Renderer (EVR) is provided for better synchronization. (By default, Overlay Mixer is chosen in Windows XP system and Enhanced Video Renderer in Windows Vista system.)

4.2 TV Settings

All TV setting tips are included within this section.

➢ Configure Analog TV / Configure Digital TV ➔ Configure TV Signal

1. Select "**Settings**" ➔ "**TV**" ➔ "**Configure Analog TV**" or "**Configure Digital TV**" ➔ "**Configure TV Signal**".
2. If you choose "Configure Analog TV" in steps 1, you need to determine the signal type: Antenna or Cable. (If the country you choose in Chapter 1.6 is USA or Canada, you can determine the signal type: Antenna, Cable-Standard and Cable-HRC.)
3. To apply the Overscan function to all channels at a time, first select **Apply All** check box.
4. Specify an appropriate number (0~20) to get the better quality.
5. Select **Save** to save the settings or select **Cancel** to abort without saving.

➢ Configure Digital TV ➔ Configure TV Signal (Only for DVB-S users)

1. Select "**Settings**" ➔ "**TV**" ➔ "**Configure Digital TV**" ➔ "**Configure TV Signal**".
2. Choose the switch type that is used by your satellite system.
3. Select **Edit** to configure your satellite information.

4. Use to select the desired Input.

5. From the **Satellite** drop down list, select the corresponding satellite or select None to create satellite information.



6. If you select None in step 5, you need to click Edit to enter the setting page. There are two options on the next page:

- **Import** : You can import any satellite channel data (*.sdx) downloaded from the Internet into application.

--Clean and add-- Delete the default satellite data and add the imported data to the program list.
--Replace duplicate item-- The imported data will overwrite the application's program list when they have the same data.
--Do not import duplicate items-- The imported data will not overwrite the application's program list when they have the same data.

- **Add** : You can add new frequencies one by one if you don't want to import any exiting satellite channel data. Please be noted after specify the satellite name and longitudem you need to select **Save** so that you can select **Add** to enter the next setting page.

7. Next, go back to the satellite page and select **Edit** to configure the LNB information.
(For details about the LNB, please refer to the documentation that comes with your LNB device.)
On this page, you need to determine the frequency type, input range, local oscillator frequency and polarization.

8. Select **Save** to save the settings or select **Cancel** to exit without saving.

9. Select **Apply** to save the current settings.

10. After all inputs' configuration has been done, select **Save** to exit with saving or select **Cancel** to exit without saving.

11. To scan digital satellite channels, select "**Settings**" ➔ "**TV**" ➔ "**Configure Digital TV**" ➔ "**Manage Programs**" ➔ "**Auto Scan**".





➢ Configure Analog TV / Configure Digital TV ➔ Manage Programs

1. Select "**Settings**" ➔ "**TV**" ➔ "**Configure Analog TV**" or "**Configure Digital TV**"➔ "**Manage Programs**".

2. Choose the desired channel.

3. If you choose "Configure Analog TV" in steps 1 and there are two or more TV systems in your area, try to select other TV system standard when the channel display looks abnormal.

4. Select **Save** to save the settings or select **Cancel** to abort without saving. If you want to revert to factory settings, select **Default**.

5. Under this menu (Manage Program), you can also scan channels, determine the channel name, change the channel order, adjust color of the display and so on. For details, refer to



➢ Configure Analog TV / Configure Digital TV / HD Input Source➔ Configure Recording

1. Select "**Settings**" ➔ "**TV**" ➔ "**Configure Analog TV**", "**Configure Digital TV**" or "**HD Input Source**" ➔ "**Configure Recording**".
2. Choose the default file format from the **Record Format** drop-down list.

3. Some formats allow you to select Edit to create your own file format.
4. Select **Save** to save the settings or select **Cancel** to abort without saving.

➢ Configure Analog TV ➔ Configure Timeshift

1. Select "**Settings**" ➔ "**TV**" ➔ "**Configure Analog TV**" ➔ "**Configure Timeshift**".
2. Choose **Normal** or **Good** video quality for timeshifting. (The default option may vary depending on the level of your CPU. For CPU of Intel Pentium D, AMD Athlon 64x2 or above, "Good" is chosen by default. Otherwise, "Normal" is set as the default option.)
3. Select **Save** to save the settings or select **Cancel** to abort without saving.

➢ Configure HD Input Source ➔ Configure Timeshift

1. Select "**Settings**" ➔ "**TV**" ➔ "**Configure HD Input Source**" ➔ "**Configure Timeshift**".
2. Choose **Normal**, **Good** or **Best** video quality for timeshifting. (The default option may vary depending on the level of your CPU.)
3. Select **Save** to save the settings or select **Cancel** to abort without saving.

➢ Configure Analog TV / Configure Digital TV ➔ Configure Color Adjustment

1. Select "**Settings**" ➔ "**TV**" ➔ "**Configure Analog TV**" or "**Configure Digital TV**" ➔ "**Configure Color Adjustment**".
2. Then use to adjust the **Brightness**, **Contrast**, **Hue**, **Saturation** and **Sharpness** until the image color is accurate.
3. To adjust the color of all channels at a time, select **Apply All** check box.
4. Select **Save** to save the settings or select **Cancel** to abort without saving. If you want to revert to factory settings, select **Default**.



☑ **Note**: For digital TV, if all items (Brightness, Contrast, Hue, Saturation, Sparpness) can't be adjusted, try to update VGA driver.

➢ More TV Options

1. Select "**Settings**" ➔ "**TV**" ➔ "**More TV Options**".
2. Make sure that your country or region is correct if you cannot get any channels after scanning.
3. If you connect to an external video device, you need to select the correct video standard.
4. If you connect to a HD device, you need to select the correct HD input source.
5. Select **Save** to save the settings or select **Cancel** to abort without saving.

4.3 Radio Settings

This section gives you more setting properties when you listening to the radio.

➢ Manage FM Radio Programs / Manage Digital Radio Programs

1. Select "**Settings**" ➔ "**Radio**" ➔ "**Configure FM Radio**" or "**Configure Digital Radio**" ➔ "**Manage Programs**".
2. Select **All Frequency Scan** when there are channels missing from the channel memory. This may take you a while, please be patient.
3. To terminate scanning, select **Stop**.
4. If you choose "**Configure FM Radio**" in step 1, select the desired channel to go to the next page.
5. You can change the audio mode of a stereo FM radio signal. Select **Mono** or **Stereo** to get better audio quality.
6. Select **Save** to save the settings or select **Cancel** to abort without saving.

➢ Configure FM Radio Recording / Configure Digital Radio Recordings

1. Select "**Settings**" ➔ "**Radio**" ➔ "**Configure FM Radio**" or "**Configure Digital Radio**" ➔ "**Configure Recording**".
2. Choose the record format from the drop down list.
3. If you choose the WMA record format in step 2, you can click the **Edit** icon to choose the preferred type of Window Media formation.
4. Select **Save** to save the settings or select **Cancel** to abort without saving.



4.4 Video Settings

1. Select "**Settings**" ➔ "**Video**".
2. Use the default folder for saving the recorded video file.
3. Or select to look for your desired folder.

4. On the next page, you can use to go up one level to find other folders or select **Change Disk** to choose other hard drives.
5. Then Choose **OK** to confirm your selection.
6. Select **Save** to save the settings or select **Cancel** to abort without saving. If you want to revert to factory settings, select **Default**.



4.5 Picture Settings

Before you start playing slide show, first check its settings to see if they fit your needs.

1. Select "**Settings**" ➔ "**Picture**".
2. From the **Play Settings** drop-down list, select **Sequential** to play a slide show in order or select **Random** to shuffle the order.
3. Type a value in the **Interval Time** text box to determine how long you want to display each picture.
4. Select the transition you want to use from the **Transition Effect** drop-down list.

5. Select to look for your desired folder.
6. On the next page, you can use to go up one level to find other folders or select **Change Disk** to choose other hard drives.
7. Choose **OK** to confirm your selection.



8. To create a slide show using all pictures in the current folder and subfolder, select **Including Sub-Folder Pictures** check box.
9. Select the **Hide window on slide show mode** check box to view pictures without video windows.
10. Select **Save** to save the settings or select **Cancel** to abort without saving. If you want to revert to factory settings, select **Default**.



4.6 About

The AVerTV application provides a convenient tool, which allows users to ask questions via AVerMedia's website easily.

1. Select "**Settings**" ➔ "**About**".
2. Make sure you have accessed to the Internet and then click **Product Information** to access the product information webpage. Or you can click **Technical Support** to connect to our technical support webpage.
3. On our web page, please enter your product version and driver version so that we can solve your problem efficiently.

Appendix

More tips and explanations are included in this chapter.

APPENDIX

Hot Keys **68**
Glossary **69**
Satellite Internet Access **71**
Universal DVB Plug-in **74**
Video Gaming Plug-in **75**
Video Quality Enhancement Plug-in **76**
Common Interface for Conditional Access **78**

Hot Keys

Hot Keys	Description
Up/Down/Left/Right arrow	Move up, down, left or right to select the desired item.
Tab	Move to next item.
Numeric keys	Use NUMERIC KEYS to directly enter the TV/Radio channel number.
Space	Confirm the selected tracks or folders when under the main menu -**Music**.
Page Up/Down	Channel Up / Channel Down
F1	Open the user manual.
F8	Turn off / on the sound.
F9	Volume Down
F10	Volume Up
Back	Back to previous page
Ctrl + A	Choose between available audio modes.
Ctrl + Shift + A	Change aspect ratio
Ctrl + D	Display the channel number.
Ctrl + Shift + D	Move backward in intervals.
Ctrl + E	A shortcut to your main menu-- “Video”.
Ctrl + F	A shortcut to your main menu-- “Radio”
Ctrl + Shift + F	Skip forward in intervals.
Ctrl + G	View EPG information.
Ctrl + I	A shortcut to your main menu-- “Pictures”
Ctrl + M	A shortcut to your main menu-- “Music”
Ctrl + N	Capture an image or a continuous sequence of images.
Ctrl + Shift + N	Play next file in the playlist.
Ctrl + O	View the recorded file list.
Ctrl + P	Freeze the playback temporarily.
Ctrl + Shift + P	Play the selected file.
Ctrl + S	Stop the playback, recording, TimeShift, etc.
Ctrl + Shift + S	Enable the TimeShift function.
Ctrl + T	A shortcut to your main menu-- “TV”
Ctrl + Shift + T	Show TV/Video programs in full screen.
Alt + Home	Go to the main page of AVer MediaCenter
Ctrl + L	Go to the previously accessed TV/Radio channel.
Ctrl + R	Record the current program.
Ctrl + Shift + R	Play previous file in the playlist.
Alt + T	View Teletext information.
Alt + B	Jump to the Blue Teletext page.
Alt + G	Jump to the Green Teletext page.
Alt + R	Jump to the Red Teletext page.
Alt + Y	Jump to the Yellow Teletext page.
Alt + Shift + S	Set the time to put your computer into Stand By/Hibernate mode, exit the application or turn off the computer.
Alt + S	Turn on/off the PIP-sizing function.
Alt + P	Turn on/off the PIP-positioning function.
Alt + M	Activate the Picture in Picture function (PIP).
Ctrl + Shift + C	Switch between available signal sources.

➢ Glossary

AVI

AVI is the most common video file format for playback on the computer. It can be saved in uncompressed form if you want high quality video, or compressed using any of the available codecs if you want to minimize the file size.

Aspect Ratio

Aspect ratio indicates the ratio of the width of an image to its height. The two most common aspect ratio of home video is 4:3 and 16:9.

DVD

When you choose this format, the recorded video file will be saved in MPEG-2 format that is compliant with DVD standards. Standard DVD frame size and frame rate are 720 x 480 pixels at 29.97 fps for NTSC and 720 x 576 at 25 fps for PAL.

DxVA

DxVA stands for DirectX Video Acceleration, which is an application programming interface (API) defined by Microsoft. It allows decoders to accelerate video playback directly on the graphics processors instead of the main CPU. This means DxVA technology can reduce the CPU usage.

H.264

Videos compressed using MPEG-4 standard are two or three times more efficient than MPEG-2. This format can be applied to a wide variety of applications or networks and systems like HD-DVD, Digital TV, Broadcast and Streaming applications.

Hibernate

Hibernation is a state in which your computer shuts down to save power but first saves everything in memory on your hard disk.

iPod

A video format base on H.264 standard but has smaller video bit rate. It's an iPod -compatible format.

MPEG-1

Choose MPEG-1 format for video files that are intended for CD-ROM playback on a computer or for Internet transmission. MPEG-1 allows file compression and offers VHS quality picture. Just about every system available today can play MPEG-1 and does not need special software or hardware.

MPEG-2

Videos compressed using MPEG-2 have extremely high quality pictures and full CD-quality sound. Choose MPEG-2 format for video files that are intended for DVD-ROM playback on a computer or if you want broadcast quality videos.

PIP (Picture in Picture)

PIP allows you to view two or more video sources at the same time wherein the small inset screens overlaid on the main screen.

PBP (Picture by Picture)

PBP allows you to view two or more video sources side by side on a display so that all channels are visible.

Stand By

Stand By is a state in which your monitor and hard

disks turn off, so that your computer uses less power.

SVCD

When you choose this format, the recorded video file will be saved in MPEG-2 format that is compliant with SVCD standards. Standard SVCD frame size and frame rate are 480 x 480 pixels at 29.97 fps for NTSC and 480 x 576 at 25 fps for PAL.

VCD

When you choose this format, the recorded video file will be saved in MPEG-1 format that is compliant with VCD standards. Standard VCD frame size and frame rate are 352 x 240 pixels at 29.97 fps for NTSC and 352 x 288 pixels at 25 fps for PAL.

WAV

A common audio file format for Windows computers. It was created by Microsoft and has become a standard PC audio file format.

Satellite Internet Access

Satellite Internet Access allows users to get faster connection to the internet via satellite. Simply follow the steps below:

> If you are using one specific satellite service to watch satellite TV and access to the internet, click **Insert** > **Import** to apply the existing satellite data from AVerTV 6.0 or AVer MediaCenter and you may skip step 1 to 4.



1. In the **Satellite Internet Access** dialog box, click **Insert** and an **Insert** dialog box appears.
2. Enter the desired name in the **Service Name** text box.
3. In the **Switch Type** section, choose the type that is used by your satellite system.
4. In the **LNB (MHz)** section, configure your own LNB information, such as input range.
5. In the **Tuner** section, specify the correct frequency, symbol rate, and polarization.
6. In **PID** section, enter the correct PID value. If there are PID values missing, it is recommended to use **Auto-Detect** to search for more PID values. After searching, all active PID will be displayed inside the box.
7. Click **OK** to save the settings or **Cancel** to leave without saving.
8. In the **Satellite Internet Access** dialog box, click **Edit** to modify the data or **Delete** to permanently remove the selected data.



	Different lamp indicates different status: • **Dark Red** indicates your satellite configuration is at wrong setting. • **Dark Green** indicates the satellite signal is available but no Internet data transmission occuring that time. • **Light Green** indicates you have connected to the Internet successfully.

9. Click **Advance** to customize the Satellite Internet Access.
   - **Start to Tray:** Select to minimize the application and an icon will appear in the notification area.
   - **Notify When Close:** Select to inform you when exiting the application.
   - **MAC Address:** By default, the system detects MAC value automatically. Or click **EDIT** to enter your MAC value.



FAQ

Q : Before setting up, what should I prepare?

A : Satellite Internet Service requires you to have an ISP account and a Modem for sending commands to the Internet.

Q : Should I pay for Satellite Internet Access?

A : The charge for the service will be mainly determined by your Internet Service Provider (ISP). For details about the fee rate, please contact your ISP.

Q : Why can't I activate Satellite Internet Access?

A : You cannot activate AVerTV 6.0/AVer MediaCenter and Satellite Internet Service at the same time so please make sure you have already exited the AVerTV 6.0/ AVer MediaCenter.

Q : Why can't I still access the Internet after setting up?

A : Our default IP address is 192.168.14.61. If there is something wrong with connecting to the website, please make sure that there is no IP address conflict in your computer.

Q : How can I get the PID value?

A : Please contact your ISP to obtain the related data.

Q : Where can I find the LNB information?

A : Refer to the documentation that comes with your LNB device.

➢ Universal DVB Plug-in

Some devices (such as AVerTV Satellite PCI / AVerTV Satellite Hybrid + FM) are shipped with a "Universal DVB" plug-in program for Windows XP or Vista Media Center Edition (MCE), providing you to watch or record DVB-S programs directly under MCE UI.

➢ Video Gaming Plug-in (for Microsoft Vista MCE only)

MCE "Video Gaming Plug In" support is for Vista MCE only. After installing the driver, you can access it through the **program library** in **Online Media**. This function enables you to watch composite/S-Video signal source or play games in Vista MCE platform. (Playing games with MCE may cause delay, but you can choose "Video Gaming Plug In" to avoid it and enjoy real-time game play.)

1. Start the **Media Center** in Vista.
2. Select "**Online Media**" ➔ **"program library"**.



3. Select **"Video Gaming Plug In"**.

4. Select the video source you want to view via **"Video Gaming Plug In"**.
5. Click button to view images in a full-screen window. Press ESC to exit the full-screen mode.

➢ Video Quality Enhancement Plug-in (for Microsoft Vista MCE only)

MCE "Video Quality Enhancement Plug-in" support is for Vista MCE only. After installing the driver, you can access it through the **program library** in **Online Media**. This function enables you to adjust the **Brightness**, **Contrast**, **Hue**, **Saturation** and **Sharpness** until the image color is accurate. The setting you made will be applied to Analog TV, and composite/S-Video signal source.

1. Start the **Media Center** in Vista.
2. Select "**Online Media**" ➔ **"program library"**.



3. Select **"Video Quality Enhancement Plug-in"**.

4. Select the item you want to adjust.

5. Use the following buttons to adjust the value of the item.

	● Decrease Brightness and Hue values by 32. ● Decrease Contrast and Saturation values by 16. ● Decrease Sharpness value by 8.
	● Decrease Brightness and Hue values by 16. ● Decrease Contrast and Saturation values by 8. ● Decrease Sharpness value by 4.
	● Decrease the item value by 1.
	Reset the item value back to its default.
	● Increase the item value by 1.
	● Increase Brightness and Hue values by 16. ● Increase Contrast and Saturation values by 8. ● Increase Sharpness value by 4.
	● Increase Brightness and Hue values by 32. ● Increase Contrast and Saturation values by 16. ● Increase Sharpness value by 8.

6. Click button to reset all items back to their default settings.

7. Or click button to save all the settings.

8. If you want to exit without saving, click button .



➢ Common Interface for Conditional Access

The AVerTV device with CI/CA enables you to watch DVB-S scrambled pay channels when you have a subscription SmartCard and an appropriate CAM (Conditional Access Module). How many scrambled channels you can watch will vary depending on the SmartCard you purchase.

1. Install the AVerTV device, SmartCard and CAM.
2. Configure DVB-S TV signal. (Please refer to *Chapter 4.2*)
3. "**Settings**" ➔ "**TV**" ➔ "**Configure Digital TV**" ➔ "**Manage Programs**" and choose **Auto Scan** to scan for channels.

4. If CAM is connected**,** when users go to the **TV** page and choose DVB-S system, the **Initializing CI** dialog will appear and begin the process of Initializing CI.
5. Click **OK** button if you learn the message and want to close the dialog. If you don't click **OK** button, the **Initializing CI** will continue anyway and the dialog will disappear when Initializing CI is done.

6. After scanning channels, the **Common Interface** dialog may appear. (The messages included in the **Common Interface** dialog will vary depending on the CAM and SmartCard you purchase.)

7. To watch TV, go to the **TV** page and you can see a preview TV window in the right-hand section of the screen.

8. To see the CI/CA information, right click on the screen, and choose **CI/CA information**. The **Common Interface** will appear.

9. Basically, you may see the information of the CAM and SmartCard and set parental control and pincode depending on the CAM and SmartCard you purchase.



(The picture here is only for reference.)

☑ **Note**:

1. With CAM connected, it is necessary to re-**Initializing CI** every time when you go to the **TV** page and switch to DVB-S system (as Step 4 shown above).
2. The messages in the **Common Interface** dialog will vary depending on the smartcard you purchase.
3. If you insert CAM and SmartCard into the CI Card Reader after you go to the TV page, you may need to restart the application to enable the CI/CA function.